

ABAT100 Series Battery Online Monitoring System

installation and operation manual V1.1

Declare

All rights reserved. Without written permission of the company, any paragraph or chapter in this manual shall not be excerpted, copied, reproduced or disseminated in any form. Otherwise, all consequences shall be borne by the violators.

The company reserves all legal rights.

We reserve the right to modify the product specifications described in this manual without prior notice. Before ordering, please contact your local distributor for new specifications of this product.

Content

| | |
|--|----|
| 1 Overview | 1 |
| 2 Product Module | 1 |
| 3 Product Description | 1 |
| 3.1 ABAT100-HS Collector Module | 1 |
| 3.2 ABAT100-S Single Battery Monitoring Module | 4 |
| 3.3 ABAT100-C Module | 5 |
| 3.4 Hall Sensor | 6 |
| 3.5 Switching Power Supply | 7 |
| 4 Communication Description | 9 |
| 4.1 Overview | 9 |
| 4.2 Protocol | 9 |
| 4.2.1 Data frame format | 9 |
| 4.2.2 Address domain | 9 |
| 4.2.3 Function domain | 10 |
| 4.2.4 Data domain | 10 |
| 4.2.5 Error check domain | 10 |
| 4.2.6 Methods of error checking | 10 |
| 4.3 Communication Address Table | 10 |
| 4.4 Communication Application | 19 |
| 4.4.1 Data reading | 19 |
| 4.4.2 Data writing | 19 |
| 4.5 Solutions to diagnose and troubleshoot common faults | 19 |
| 4.5.1 Abnormal data after device power up | 19 |
| 4.5.2 Abnormal RS-485 communication | 19 |
| 4.5.3 No data for single modules | 19 |

1 Overview

Acrel ABAT100 series battery online monitoring system can provide battery operation information such as voltage, internal resistance and internal temperature, including SOC and SOH, and can provide early warning and battery equalization for failed batteries to guarantee battery pack backup time and extend battery pack life. The system has monitoring functions, and is easy to install, maintain and access. The system mainly consists of ABAT100-S single battery monitoring module, ABAT100-C group battery monitoring module, ABAT100-HS collector module and touch screen, etc. The alarm and real-time data can be queried and parameters can be set through the touch screen, and the monitoring platform can be selected to realize networked centralized management.

2 Product Module

| Model | Function Description |
|--------------|---|
| ABAT100-HS | DC24V input, one to manage a group of batteries, up to 120 batteries in a group. |
| ABAT100-S-02 | Monitor one 2V battery, monitor battery voltage, internal resistance and negative terminal temperature. |
| ABAT100-S-06 | Monitor one 6V battery, monitor battery voltage, internal resistance and negative terminal temperature. |
| ABAT100-S-12 | Monitor one 12V battery, monitoring battery voltage, internal resistance and negative terminal temperature. |
| ABAT100-C | Monitor one charge/discharge current with an ambient temperature with a maximum current range of 1000A. |




Fig.1 Dimensions of ABAT100 series module

3 Product Description

3.1 ABAT100-HS Collector Module

Introduction

The ABAT100-HS collector module is used as a management module for a group of battery packs to read the battery monitoring data from the front-end single battery monitoring sub-module and analyze and process the data, which can estimate the remaining capacity of each battery and the whole group of batteries. The operation parameters can be set directly by matching with the touch screen, and the collected data can be viewed directly. The collector module will automatically save the key battery data periodically and can be sent to the third party monitoring system through RS485 port, supporting MODBUS protocol. One collector module manages one group of batteries, and the maximum number of manageable modules is 120.

Network solution 1: Touch screen serial port acquisition network solution




Fig.2 Network plan 1

Network solution 2: AcreEMS, EIOT platform network solution




Fig.3 Network plan 2

| Function | Description |
|-------------------------|---|
| Display | Real-time data display, graphs, histogram display |
| Historical Data | Query and export of equipment operation history, charging and discharging records and monitoring events |
| Parameter Configuration | Provide basic information management functions |
| Communication protocol | MODBUS-RTU |
| Alarm mode | Local audible and visual alarm, indicator alarm, SMS alarm, etc. |
| Capacity estimation | Group batteries SOC, SOH estimation; single battery SOC, SOH estimation |
| Regular inspection | Intelligent judgment of the current state and automatic issuance of test commands |
| Indicator light | Red and green LED lights, green light as the power light, red light as the indicator light |



Fig.4 ABAT100-HS module

| Technical parameters | Description |
|------------------------------|--|
| Working Environment | Operating temperature: -10°C~50°C Relative humidity: 5%~95% Atmospheric pressure intensity: 80~110kPa |
| Management Capability | One collector can monitor a maximum of total 120 batteries |
| Alarm Type | Group voltage overcharge/discharge, single voltage overcharge/discharge, current overcharge/discharge, high internal resistance of single unit, abnormal communication, etc. |
| Power Supply | DC24V |
| Protection | With overvoltage and short circuit protection |
| Communication Interface | With RS485 communication port, support MODBUS/RTU |
| Insulation withstand voltage | 2000VAC |
| Installation method | Tie-down mounting or adhesive mounting |
| Weight | 90g |

3.2 ABAT100-S Single Battery Monitoring Module

Introduction

ABAT100-S single battery monitoring module (S module) can be embedded into existing monitoring system to achieve online monitoring of each backup battery voltage, internal resistance and negative battery temperature, in accordance with ANSI/TIA-942 standard requirements. The monitoring system controls and reads data by sending MODBUS commands to the S-module, and performs internal resistance testing, each S-module has a settable address. S-modules are extremely simple and easy to install and wire, and can be directly attached to the battery with detachable connecting wires, which does not affect the battery operation during construction.

| Function | Description |
|----------------------------------|---|
| Online monitoring | Online monitoring 24 hours a day, one battery per module, monitoring voltage, internal resistance and negative terminal temperature |
| High accuracy measurement | Internal resistance measurement error as low as 1% |
| Battery internal resistance test | Automatic periodic measurement of the internal resistance of each battery controlled by the collector |
| Low power design | Manual entry into low power mode, S-module draws current from the battery down to 0.5mA |
| Anti-jamming design | High anti-interference design, can block the ripple interference of high power high frequency UPS |
| Communication protocol | MODBUS-RTU protocol |
| Installation method | Tie-down mounting or adhesive mounting |
| Indicator light | Red and green LED lights, green light as the power light, red light as the indicator light |



Fig. 5 ABAT100-S module

| Technical parameters | Description | | |
|--------------------------------|---|-------------|------------------|
| Working Environment | Operating temperature: -10°C~50°C Relative humidity: 5%~95% Atmospheric pressure intensity: 80~110kPa | | |
| Monitoring Capability | One S-module monitors one battery | | |
| Monitoring Scope | 2V, 6V, 12V battery with capacity less than 3000AH | | |
| Measurement range and accuracy | Measurement content | Scope | Accuracy |
| | Single Voltage | 2V, 6V, 12V | ±0.1% |
| | Single internal resistance | 50~65535uΩ | (Resolution) 1uΩ |

| | | | |
|------------------------------|---|-------------|------|
| | Negative temperature | -5°C~+105°C | ±1°C |
| Power requirements | Directly from the monitored battery, 2V module normal operation of the absorption current of 10mA, the maximum is not more than 13mA, 6V, 12V module normal operation of the absorption current of 5mA, the maximum is not more than 7mA, different modules absorption current consistency is very high | | |
| Protection | Measuring circuit and power circuit with two levels of protection, with reverse connection protection and opto-isolation | | |
| Communication Interface | UART port, support MODBUS protocol | | |
| Insulation withstand voltage | 2000VAC | | |
| Weight | 90g | | |

3.3 ABAT100-C Module

Introduction

The ABAT100-C battery monitoring module (C module) can be embedded into existing monitoring systems for online monitoring of battery charge and discharge current and ambient temperature. The monitoring system controls and reads data by sending MODBUS commands to the C-module, and each C-module has a settable address. the C-module is extremely simple and easy to install and wire, and can be directly attached to the battery with removable connection cable, which does not affect the battery operation during construction.

| Function | Description |
|------------------------|---|
| High stability | Reliable and stable long-term operation |
| Anti-jamming design | High anti-interference design, can block the ripple interference of high power high frequency UPS |
| Communication protocol | MODBUS-RTU Protocol |
| Installation method | Tie-down mounting or adhesive mounting |
| Indicator light | Red and green LED lights, green light as the power light, red light as the indicator light. |



Fig.6 ABAT100-C module

| Technical parameters | Description |
|----------------------|---|
| Working Environment | Operating temperature: -10°C~50°C Relative humidity: 5%~95% Atmospheric pressure intensity: 80~110kPa |

| | | | |
|--------------------------------|--|-------------|----------|
| Monitoring Capability | One C-module monitors the charge and discharge current of a group of batteries against the ambient temperature | | |
| Monitoring Scope | 2V, 6V, 12V battery pack | | |
| Measurement range and accuracy | Measurement content | Scope | Accuracy |
| | Charging and discharging current | 0~1000A | ±1% |
| | Ambient temperature | -5°C~+105°C | ±1°C |
| Power requirements | DC24V, 1W | | |
| Protection | Measurement circuit and power circuit with two levels of protection | | |
| Communication Interface | UART port, support MODBUS protocol | | |
| Insulation withstand voltage | 2000VAC | | |
| Weight | 90g | | |

3.4 Hall Sensor

Introduction

AHKC-EKC series open type Hall current sensor powered by ABAT100-C module is a new generation of current sensor developed by applying Hall effect principle, which can measure DC, AC, pulse and various irregular waveform currents under galvanic isolation conditions.



Fig.7 AHKC-EKC series open type Hall current sensor

| Parameters | Indicators |
|--------------------------------|-----------------------------------|
| Rated input current | 0~(500-1500)A |
| Rated output voltage | ±5V |
| Accuracy class | 1.0 |
| Supply voltage | DC±15V (Allowed fluctuation ±20%) |
| Zero point out-of-tune voltage | ±20mV |
| Out-of-tune voltage drift | ≤±2.0mV/°C |
| Linearity | ≤0.2%FS |
| Response time | ≤5us |
| Bandwidth | 0~20kHz |
| Insulation voltage | 2.5kV/50Hz/1min |
| Operating temperature | -40°C~85°C |

| | |
|---------------------|------------|
| Storage temperature | -40°C~85°C |
| Power consumption | ≤0.5W |




Fig.8 Dimensions of AHKC-EKC series open type Hall current sensor

3.5 Switching Power Supply

Introduction

The KDYA-DG1502-12K switching power supply is used to power the ATP010KT touch panel and ABAT100-HS module.



Fig.9 KDYA-DG1502-12K switching power supply

| | | |
|-------|---------------------|---|
| Name | KDYA-DG1502-12K | |
| Input | Voltage and current | AC 85 - 264V or DC 100 - 230V 0.3A / 230VAC |
| | Frequency | 47-63Hz or DC |
| | Gush | 28A / 230VAC / 20ms Initial power-on time |
| | Leakage current to | -- |

| | | |
|---------------|--------------------------|---|
| | ground | |
| | Typical efficiency value | 80% |
| Output | Voltage | $\pm 12.0V \pm 1\%$ |
| | Current | 0 - 0.6A |
| | Ripple noise | $\leq 45mV$ |
| | Voltage regulation | -- |
| | Temperature stability | 300ppm/°C -Vrate |
| | Adjustment rate | < 0.5% |
| | Rated power | 15W |
| | Overshoot | Overshoot <5% when the power is on or off, and <2% for every 30% change in load |
| | Response | Response time is 1ms for every 30% change in load with a change rate of 1A/us |
| Time Response | | 300ms/20ms/16ms start, build, hold |
| Protection | Over-voltage protection | 16V |
| | Overload | When the output power exceeds 18--30W, the output voltage will start to drop, and then enter into foldback protection when the load is heavier. |
| | Short Circuit | Output is foldback protection |
| | Overheat protection | Built-in temperature protection on the chip |
| Environment | Work | -25--+70°C, 10--90%RH (no condensation), full load use. Temperature higher than 70°C reduced use |
| | Storage | -35--+85°C, 5--95%RH (no condensation) |
| | Vibrations | 10--500Hz, 2G 10 minutes/1 cycle, along X, Y, Z axis, each axis direction for a total of 60 minutes |
| Security | Insulation resistance | Input to output $\geq 50M\Omega$ (500VDC) |
| | Pressure resistance | Input to output: AC3.0KV/10mA/1min |
| | Standard | Comply with the relevant provisions of UL508, GB4943, TUV, EN60950 and other standards |
| EMC | EMS | Level 4 |
| | EMI | Class B |
| MTBF | | 100 000 hours |
| Dimension | | 72×63×27 |
| Weight | | 90g |
| Cautions | | 1. The test is in the specified conditions, the input voltage is the rated voltage, the test environment is conventional laboratory conditions. |
| | | 2. Ripple and noise are measured directly at the 20MHz bandwidth terminal. |
| | | 3. Considering that the power supply may be installed on the final equipment, the equipment shall comply with EMC related regulations. |

Dimensional drawing




Fig.10 Dimensions of KDYA-DG1502-12K switching power supply

4 Communication Description

4.1 Overview

The ABAT100-S single battery monitoring module and the ABAT100-C group battery monitoring module are only used for TTL communication with the ABAT100-HS collector module using the Modbus-RTU protocol: the default parameters are listed in the following table:

| Communication method | Baud rate | Data bits | Check digit |
|----------------------|-----------|-----------|-------------|
| TTL | 9600 | 8 | N |

The ABAT100-HS collector module communicates with the host PC with RS485, using the Modbus-RTU protocol: the default parameters are listed in the table below:

| Communication method | Baud rate | Data bits | Check digit |
|----------------------|-----------|-----------|-------------|
| 485 | 19200 | 8 | N |

Note: n means no parity bit; error detection: CRC16 (cyclic redundancy parity)

4.2 Protocol

The protocol is the standard Modbus-RTU protocol, which reads as follows

4.2.1 Data frame format

| Address | Function | Data | Calibration |
|---------|----------|----------|-------------|
| 8-Bits | 8-Bits | NX8-Bits | 16-Bits |

4.2.2 Address domain

The address domain is at the beginning of the frame and consists of one byte (8-Bits, 8-bit binary code), decimal 0 to 255, in our system only 1 to 247 are used, other addresses are reserved. These bits mark the address of the user-specified terminal device that will receive data from the host to which it is connected. The address of each terminal device on the same bus must be unique, and only the terminal addressed will respond to a query containing that address. When a terminal sends back a response, the slave address data in the response tells the host which terminal is communicating with it.

4.2.3 Function domain

The function domain codes tell the terminal being addressed what function to perform. The following table lists the function codes used by this family of instruments, along with their meaning and function.

| Code (hexadecimal) | Meaning | Behavior |
|--------------------|-----------------------|---|
| 03H | Read Holding Register | Get the current binary value in one or more holding registers |
| 10H | Preset multi register | Load the specific binary value into a series of holding registers |

4.2.4 Data domain

The data domain contains data required by the terminal to perform a specific function or data captured by the terminal in response to a query. These data may be numeric values, parametric addresses, or setting values.

For example, the function domain tells the terminal to read a register, while the data domain needs to specify which register to start from and how many data to read, with embedded addresses and data varying by type and slave.

4.2.5 Error check domain

The domain uses CRC16 cyclic redundancy checks to allow hosts and terminals to check for errors during transmission. Sometimes due to electrical noise and other interferences, a set of data may change on the line when it is transmitted from one device to another. Error checks can ensure that the host or slave does not respond to those changed data, which improves the security, reliability and efficiency of the system.

4.2.6 Methods of error checking

The error check domain occupies two bytes and contains a 16-bit binary value. the CRC value is calculated by the transmitting device and then appended to the data frame. the receiving device recalculates the CRC value when accepting the data and then compares it with the value in the received CRC domain. if the two values are not equal, an error has occurred.

In CRC operation, first a 16-bit register is preset to all 1s, then 8 bits of each byte in the data frame are successively operated with the current value of the register, only the 8 data bits of each byte are involved in generating the CRC, the start and stop bits and the parity bits that may be used do not affect the CRC. 8 bits of each byte are iso-ored with the contents of the register when generating the CRC. Then the result is shifted to the lower bit, the higher bit is supplemented with "0", the lowest bit (LSB) is shifted out and detected, if it is 1, the register performs an iso-or operation with a preset fixed value (0A001H), if the lowest bit is 0, no processing is done. CRC generation flow:

1) Preset a 16-bit register as 0FFFFH (all 1s), called CRC register.

The 8 bits of the first byte in the CRC register are iso-or operated with the low byte in the CRC register, and the result is stored back in the CRC register.

2) The 8 bits of the first byte in the data frame are iso-or operated with the low byte in the CRC register, and the result is stored back in the CRC register.

3) Shift the CRC register one bit to the right, fill the highest bit with 0 and shift the lowest bit out and detect.

4) If the lowest shift out is 0: repeat step 3 (next shift); if the lowest shift out is 1: connect the CRC register with a preset fixed

The fixed value (0A001H) is used to perform the different or operation.

5) Repeat step 3 and step 4 until 8 shifts. This finishes processing a complete 8 bits.

6) Repeat step 2 to step 5 to process the next 8 bits until all bytes are processed.

7) The final CRC register value is the value of CRC. There is also a method to calculate CRC using table lookup, its main feature is fast calculation, but the table requires a large storage space, the method is not repeated here, please consult the relevant information.

4.3 Communication Address Table

4.3.1 HS module parameter address

Overview

HS module parameter address mainly contains 4 parts, for communication parameter address, status parameter address, group parameter threshold address, single data address, using MODBUS-RTU protocol, supporting 0x03, 0x06, 0x10 commands, where up to 127 registers are continuously read and up to 20 registers are continuously written.

4.3.1.1 Communication parameter addresses

| Serial number | Address | Variables | Remarks | Length (Bytes) | Description | Type |
|---------------|---------|--|---------|----------------|--------------------------------|------|
| 0 | 0000H | Reserved | | | | |
| 1 | 0001H | Reserved | | | | |
| 2 | 0002H | Address | R/W | 2 | Default 1 | U16 |
| 3 | 0003H | Downstream TTL communication Baud rate | R/W | 2 | 0 :4800 1 :9600 2 :19200 | U16 |

| | | | | | | |
|-------|-------------|--|-----|---|---|-----|
| | | | | | Default 9600 | |
| 4 | 0004H | TTL parity stop bit | R | 2 | 1 Stop bit No calibration | U16 |
| 5 | 0005H | 485 communication baud rate | R/W | 2 | 0:1200 1:2400 2:4800 3:9600 4:19200 5:38400 19200 | U16 |
| 6 | 0006H | 485 check stop bit | R/W | 2 | High 8 bits 0:None 1:Even 2:Odd Lower 8 bits 0:1 stop bit 1:2 stop bits Default None, 1 stop bit | U16 |
| 7~19 | 0007H~0013H | Reserved | | | | |
| 20 | 0014H | Types of single modules | R/W | 2 | 2V 6V 12V | U16 |
| 21 | 0015H | Number of groups | R | 2 | Default value 1 | U16 |
| 22 | 0016H | Group 1 Number of single modules | R/W | 2 | 1~120 | |
| 23 | 0017H | Group 1 single battery capacity | R/W | 2 | Unit:AH | U16 |
| 24~34 | 0018H~0022H | Reserved | | | | |
| 35 | 0023H | Automatic testing of internal resistance cycle | R/W | 2 | (1~30) | U16 |
| 36 | 0024H | Automatic testing of internal resistance time | R/W | 2 | High 8:Time Lower 8 bits:minutes | U16 |

4.3.1.2 Status parameter addresses

| Serial number | Address | Variables | Remarks | Length (Bytes) | Description | Type |
|---------------|---------|--|---------|----------------|--|------|
| 100 | 0064H | Reserved | | | | |
| 101 | 0065H | Initialization | R/W | 2 | High Byte:0xF0 Initialization group parameter threshold Low byte:0xF0 Clear event logs | U16 |
| 102 | 0066H | Device Reset | R/W | 2 | 0xf0f0 Reset HS module | U16 |
| 103 | 0067H | Year/month | R/W | 2 | | U16 |
| 104 | 0068H | Day/Hour | R/W | 2 | | U16 |
| 105 | 0069H | Minutes/second | R/W | 2 | | U16 |
| 106 | 006AH | Low power consumption | R/W | 2 | 0xf1f1: Turn on whole group low power 0xf0f0: Turn off the whole group of low power consumption | U16 |
| 107 | 006BH | Automatic testing of internal resistance | R/W | 2 | 0xf0f0: Turn on all tests 0xF1mm: Turn on the current group of 0xmm size battery test | U16 |
| 108 | 006CH | Equipment working status | R/W | 2 | 2:Working state 3:Internal resistance test | U16 |

| | | | | | | |
|---------|-------------|---|-----|---|--|-----|
| 109 | 006DH | Battery Status | R/W | 2 | 0: Floating charge 1: Discharge 2: Charging | U16 |
| 110~111 | 006EH~006FH | Reserved | | | | |
| 112 | 0070H | Manual equalization function activated | R/W | 2 | 0xf0f0: Whole group balance | U16 |
| 113 | 0071H | Manual equalization Single number | R/W | 2 | 0xmm: Balanced 0xmm monoblock | U16 |
| 114 | 0072H | Longitudinal internal resistance reference value reset mark | R/W | 2 | 0xf0f0: Setting the current value of the internal resistance of all batteries to the reference value; 0xmm: Set the current internal resistance of the 0xmm number as the reference for that single module; 0x0101: The average value of the current internal resistance of all batteries is used as the reference for the whole group. | U16 |
| 115 | 0073H | Reserved | | | | |
| 116 | 0074H | Modify the current direction flag/Hall calibration zero | R/W | 2 | 0x6400: Enabling Hall zero drift calibration; 0x6401: Turn off Hall zero drift calibration; 0xf0f0: Change the direction of the current. | U16 |

4.3.1.3 Group parameter threshold address

| Serial number | Address | Variables | Remarks | Length (Bytes) | Description | Type |
|---------------|---------|---|---------|----------------|-------------|------|
| 1000 | 3E8H | Single voltage overcharge alarm value | R/W | 2 | Unit: mV | U16 |
| 1001 | 3E9H | Reserved | | | | |
| 1002 | 3EAH | Single voltage over discharge alarm value | R/W | 2 | Unit: mV | U16 |
| 1003 | 3EBH | Reserved | | | | |
| 1004 | 3ECH | Single floating charge voltage too high alarm value | R/W | 2 | Unit: mV | U16 |
| 1005 | 3EDH | Reserved | | | | |
| 1006 | 3EEH | floating charge voltage too low alarm value | R/W | 2 | Unit: mV | U16 |
| 1007 | 3EFH | Reserved | | | | |
| 1008 | 3F0H | Uneven voltage alarm value for a single unit | R/W | 2 | Unit: mV | U16 |
| 1009 | 3F1H | Reserved | | | | |
| 1010 | 3F2H | Single voltage extreme difference value alarm value | R/W | 2 | Unit: mV | U16 |
| 1011 | 3F3H | Reserved | | | | |
| 1012 | 3F4H | Overall voltage overcharge alarm value | R/W | 2 | Unit: 0.1V | U16 |
| 1013 | 3F5H | Reserved | | | | |

| | | | | | | |
|------|------|---|-----|---|----------------------------|-----|
| 1014 | 3F6H | Overall voltage overdischarge alarm value | R/W | 2 | Unit: 0.1V | U16 |
| 1015 | 3F7H | Reserved | | | | |
| 1016 | 3F8H | Overall floating charge voltage over protection alarm value | R/W | 2 | Unit: 0.1V | U16 |
| 1017 | 3F9H | Reserved | | | | |
| 1018 | 3FAH | Overall low float voltage alarm value | R/W | 2 | Unit: 0.1V | U16 |
| 1019 | 3FBH | Reserved | | | | |
| 1020 | 3FCH | Charging overcurrent alarm value | R/W | 2 | Unit: 0.1A Default 536 | U16 |
| 1021 | 3FDH | Reserved | | | | |
| 1022 | 3FEH | Discharge overcurrent alarm value | R/W | 2 | Unit: 0.1A Default 500 | U16 |
| 1023 | 3FFH | Reserved | | | | |
| 1024 | 400H | Ambient high temperature alarm value | R/W | 2 | Unit: 0.1°C Default 500 | S16 |
| 1025 | 401H | Reserved | | | | |
| 1026 | 402H | Ambient low temperature alarm value | R/W | 2 | Unit: 0.1°C Default 0 | S16 |
| 1027 | 403H | Reserved | | | | |
| 1028 | 404H | | | | | |
| 1029 | 405H | | | | | |
| 1030 | 406H | Battery high temperature alarm value | R/W | 2 | Unit: 0.1°C Default 500 | S16 |
| 1031 | 407H | Reserved | | | | |
| 1032 | 408H | Battery low temperature alarm value | R/W | 2 | Unit: 0.1°C Default 0 | S16 |
| 1033 | 409H | Reserved | | | | |
| 1034 | 40AH | Uneven battery temperature alarm value | R/W | 2 | Unit: 0.1°C Default 50 | S16 |
| 1035 | 40BH | Reserved | | | | |
| 1036 | 40CH | Excessive internal resistance level 2 alarm factor | R/W | 2 | Unit 0.1% Default 1500 | U16 |
| 1037 | 40DH | Excessive internal resistance level 1 alarm factor | R/W | 2 | Unit 0.1% Default 1300 | U16 |
| 1038 | 40EH | Uneven internal resistance alarm factor | R/W | 2 | Unit 0.1% Default 300 | U16 |
| 1039 | 40FH | Reserved | | | | |
| 1040 | 410H | Small internal resistance alarm factor | R/W | 2 | Unit 0.1% Default 50 | U16 |
| 1041 | 411H | Reserved | | | | |
| 1042 | 412H | | | | | |
| 1043 | 413H | | | | | |
| 1044 | 414H | | | | | |
| 1045 | 415H | | | | | |
| 1046 | 416H | | | | | |
| 1047 | 417H | | | | | |
| 1048 | 418H | SOC low alarm value | R/W | 2 | Unit 0.1% Default 300 | U16 |
| 1049 | 419H | Reserved | | | | |
| 1050 | 41AH | SOH low alarm value | R/W | 2 | Unit 0.1% Default 400 | U16 |
| 1051 | 41BH | Reserved | | | | |
| 1052 | 41CH | Internal resistance reference value 1# | R/W | 2 | Unit:μΩ Default 0 | U16 |
| 1053 | 41DH | Internal resistance reference value 2# | R/W | 2 | Unit:μΩ Default 0 | U16 |
| 1054 | 41EH | Internal resistance reference value | R/W | 2 | Unit:μΩ | U16 |

| | | | | | | |
|-------|-------|---|-------|-------|----------------------|-------|
| | | 3# | | | Default 0 | |
| | | | | | | |
| | | | | | | |
| 1171 | 493H | Internal resistance reference value 120# | R/W | 2 | Unit:μΩ Default 0 | U16 |

4.3.1.4 Single data address

| Category | Serial number | Address | Variables | Remarks | Length (Bytes) | Description | Type |
|---------------------------------|-----------------|---------|--|---------|----------------|--|-------|
| Single Voltage Data | 10001 | 2711H | Voltage 1# | R | 2 | Unit mV | U16 |
| | 10002 | 2712H | Voltage 2# | R | 2 | | U16 |
| | 10003 | 2713H | Voltage 3# | R | 2 | | U16 |
| | | | | | | | |
| | 10120 | 2788H | Voltage 120# | R | 2 | | U16 |
| | 10121 | 2789H | Voltage update time: year/month | R | 2 | | U16 |
| | 10122 | 278AH | Day/Hour | R | 2 | | U16 |
| | 10123 | 278BH | Minutes/second | R | 2 | | U16 |
| | 10124~ 10130 | | | | | | |
| Single internal resistance data | 10131 | 2793H | Internal resistance 1# | R | 2 | Unit μΩ | U16 |
| | 10132 | 2794H | Internal resistance 2# | R | 2 | | U16 |
| | 10133 | 2795H | Internal resistance 3# | R | 2 | | U16 |
| | | | | | | | |
| | 10250 | 280AH | Internal resistance 120# | R | 2 | | U16 |
| | 10251 | 280BH | Internal resistance update time: year/month | R | 2 | | U16 |
| | 10252 | 280CH | Day/Hour | R | 2 | | U16 |
| | 10253 | 280DH | Minutes/second | R | 2 | | U16 |
| | 10254~ 10260 | | | | | | |
| Single temperature data | 10261 | 2815H | Single temperature 1# | R | 2 | Unit 0.1°C | S16 |
| | 10262 | 2816H | Single temperature 2# | R | 2 | | S16 |
| | 10263 | 2817H | Single temperature 3# | R | 2 | | S16 |
| | | | | | | | |
| | 10380 | 288CH | Single temperature 120# | R | 2 | | S16 |
| | 10381 | 288DH | Temperature update time: year/month | R | 2 | | U16 |
| | 10382 | 288EH | Day/Hour | R | 2 | | U16 |
| | 10383 | 288FH | Minutes/second | R | 2 | | U16 |
| | 10384~ 10390 | | | | | | |
| Single alarm fault 1 | 10391 | 2897H | Battery alarm status 1-1# | R | 2 | Each bit represents a state that A value of 0 indicates normal and a value of 1 indicates an alarm. Starting from B0, the sequence is expressed as Single voltage alarm (0), Single voltage 0:high/1:low (1), Single voltage alarm level (2-3), the Single internal resistance alarm (4), Single internal resistance 0:high/1:low (5), Single internal resistance alarm level (6-7), | U16 |
| | 10392 | 2898H | Battery alarm status 1-2# | R | 2 | | U16 |
| | 10393 | 2899H | Battery alarm status 1-3# | R | 2 | | U16 |
| | | | | | | | |
| | 10510 | 290EH | Battery alarm status 1-120# | R | 2 | | U16 |

| | | | | | | | |
|------------------------|-------|-------|----------------------------------|-------|-------|---|-------|
| | | | | | | Single temperature alarm (8), Single temperature 0:high/1:low (9), Single temperature alarm level (10-11), the Reservation (12-15) | |
| Single alarm failure 2 | 10511 | 290FH | Battery alarm status 2-1# | R | 2 | Each bit represents a state that A value of 0 indicates normal and a value of 1 indicates protection. Starting from B0, the sequence is expressed as Uneven voltage of Single (0), Uneven temperature of the Single (1), the Uneven internal resistance of the Single (2), the High float charging voltage (3), Low floating charge pressure (4), Battery open circuit (5), Reservation (6), Battery ground alarm (7), Retention (8-15) | U16 |
| | 10512 | 2910H | Battery alarm status 2-2# | R | 2 | | U16 |
| | 10513 | 2911H | Battery alarm status 2-3# | R | 2 | | U16 |
| | | | | | | | |
| | 10630 | 2986H | Battery alarm status 2-120# | R | 2 | U16 | |
| Single Status | 10631 | 2987H | Equipment operation status 1# | R | 2 | Each bit represents a state that A value of 0 indicates normal and a value of 1 indicates abnormal. From B0 onwards, it is expressed as Single voltage (0), Battery temperature(1), Reservation (2), Single internal resistance test (3), Internal resistance test battery voltage abnormality (4), Internal resistance test discharge current is abnormal (5), S module communication abnormality (6), Retention (7-15) | U16 |
| | 10632 | 2988H | Equipment operation status 2# | R | 2 | | U16 |
| | 10633 | 2989H | Equipment operation status 3# | R | 2 | | U16 |
| | | | | | | | |
| | 10750 | 29FEH | Equipment operating status 120# | R | 2 | U16 | |
| Group measurement data | 10751 | 29FFH | Group pressure | R | 2 | Unit:0.1V | U16 |
| | 10752 | 2A00H | External group pressure | R | 2 | Unit: 0.1V Valid for SV module | U16 |
| | 10753 | 2A01H | Charging and discharging current | R | 2 | Unit:0.1A Charging is negative Discharge is positive | S16 |
| | 10754 | 2A02H | Floating charge flow | R | 2 | Unit:0.001A | U16 |
| | 10755 | 2A03H | Ambient temperature 1 | R | 2 | Unit:0.1°C | S16 |
| | 10756 | 2A04H | Ambient temperature 2 | R | 2 | Unit:0.1°C Valid for TR module | S16 |
| | 10757 | 2A05H | Maximum voltage | R | 2 | | U16 |

| | | | | | | | | |
|---|-------------|-------------|--|---|---|------------|-----|--|
| | | | battery number | | | | | |
| | 10758 | 2A06H | Maximum battery voltage value | R | 2 | Unit:mV | U16 | |
| | 10759 | 2A07H | Minimum voltage battery number | R | 2 | | U16 | |
| | 10760 | 2A08H | Minimum battery voltage value | R | 2 | Unit:mV | U16 | |
| | 10761 | 2A09H | Average battery voltage per battery | R | 2 | Unit:mV | U16 | |
| | 10762 | 2A0AH | Average difference of battery voltage | R | 2 | Unit:mV | U16 | |
| | 10763 | 2A0BH | Battery voltage polarity value | R | 2 | Unit:mV | U16 | |
| | 10764 | 2A0CH | Maximum internal resistance battery number | R | 2 | | U16 | |
| | 10765 | 2A0DH | Maximum internal battery resistance value | R | 2 | Unit:μΩ | U16 | |
| | 10766 | 2A0EH | Minimum internal resistance battery number | R | 2 | | U16 | |
| | 10767 | 2A0FH | Minimum battery internal resistance value | R | 2 | Unit:μΩ | U16 | |
| | 10768 | 2A10H | Average battery internal resistance value | R | 2 | Unit:μΩ | U16 | |
| | 10769 | 2A11H | Maximum temperature battery number | R | 2 | | U16 | |
| | 10770 | 2A12H | Maximum battery temperature value | R | 2 | Unit:°C | S16 | |
| | 10771 | 2A13H | Minimum temperature battery number | R | 2 | | U16 | |
| | 10772 | 2A14H | Minimum battery temperature value | R | 2 | Unit:°C | S16 | |
| | 10773 | 2A15H | Average battery temperature value | R | 2 | Unit:°C | S16 | |
| | 10774 | 2A16H | Group SOC | R | 2 | Unit:0.1% | U16 | |
| | 10775 | 2A17H | Group SOH | R | 2 | Unit:0.1% | U16 | |
| | 10776 | 2A18H | Reserved | | | | | |
| | 10777 | 2A19H | Reserved | | | | | |
| | 10778 | 2A1AH | Insulation positive resistance | R | 2 | Unit:KΩ | U16 | |
| | 10779 | 2A1BH | Insulation negative resistance | R | 2 | Unit:KΩ | U16 | |
| | 10780 | 2A1CH | Reserved | | | | | |
| | 10781 | 2A1DH | Reserved | | | | | |
| | 10782 | 2A1EH | Maximum rate of change of internal resistance battery number | R | 2 | | U16 | |
| | 10783 | 2A1FH | Maximum rate of change of internal resistance value | R | 2 | Unit:0.01% | U16 | |
| | 10784~10790 | 2A20H~2A26H | Reserved | | | | | |
| Single internal resistance change rate data | 10791 | 2A27H | Single internal resistance change rate 1# | R | 2 | Unit:0.01% | U16 | |
| | 10792 | 2A28H | Single internal resistance change rate 2# | R | 2 | Unit:0.01% | U16 | |

| | | | | | | | |
|----------------------|-------|-------|---|-------|-------|---|-------|
| | 10793 | 2A29H | Single internal resistance change rate 3# | R | 2 | Unit:0.01% | U16 |
| | | | | | | | |
| | 10910 | 2A9EH | Single internal resistance change rate 120# | R | 2 | Unit:0.01% | U16 |
| Group 1 alarm status | 10911 | 2A9FH | Alarm 1 | R | 2 | Two registers are one unit, each representing an alarm, a 1 means that this level of alarm is defined, and a 0 vice versa. Starting from B0, the sequence is expressed as Group pressure high (0), Group pressure is low (1), High charging current (2), High discharge current (3), High ambient temperature (4), Low ambient temperature (5), Floating charge group pressure high (6), Floating charge group depression (7), Excessive differential pressure (8), Low SOC (9), SOH is low (10), the Battery thermal runaway (11), Reserved (12-15) | U16 |
| | 10912 | 2AA0H | Alarm 2 | R | 2 | High Single voltage (0), Single voltage is low (1), High Single internal resistance (2), Low Single internal resistance (3), High battery temperature (4), Low battery temperature (5), Uneven voltage (6), Uneven temperature of the Single (7), the Uneven internal resistance of the Single (8), the High float charging voltage (9), Floating charge depression (10), Reservation (11-15) | U16 |
| | 10913 | 2AA1H | Alarm 3 | R | 2 | SV group voltage module communication (0), C charging and discharging current | U16 |
| | | | | | | | |

| | | | | | | | | |
|--------------------|-----------------|---------------------|-------------------------------|-------|-------|--|-------|--|
| | | | | | | module communication (1), TR floating charge flow module communication (2), Ambient temperature module communication (3), Retention (4-9) Insulation module communication (10), Retention (11-12), Internal resistance test floating charge current abnormality (13), Retention (14-15) | | |
| | 10914 | 2AA2H | Alarm 4 | R | 2 | Single voltage (0), Battery temperature(1), Reservation (2), Single internal resistance test (3), Retention (4-5), S module communication abnormality (6), Retention (7-15) | U16 | |
| | 10915~ 11000 | 2AA3H ~ 2AF8H | Reserved | | | | | |
| Single SOC data | 11001 | 2AF9H | SOC1# Single SOC1# | R | 2 | Unit:0.1% | U16 | |
| | 11002 | 2AFAH | SOC2# Single SOC2# | R | 2 | | U16 | |
| | 11003 | 2AFBH | SOC3# Single SOC3# | R | 2 | | U16 | |
| | | | | | | | | |
| | 11120 | 2B70H | SOC120# Single SOC120# | R | 2 | | U16 | |
| | 11121 | 2B71H | SOC updated on: Year/month | R | 2 | | U16 | |
| | 11122 | 2B72H | Day/Hour | R | 2 | | U16 | |
| | 11123 | 2B73H | Minutes/second | R | 2 | | U16 | |
| | 11124~ 11130 | Reserved | | | | | | |
| Single SOH data | 11131 | 2B7BH | SOH1# Single SOH1# | R | 2 | Unit:0.1% | U16 | |
| | 11132 | 2B7CH | SOH2# Single SOH2# | R | 2 | | U16 | |
| | 11133 | 2B7DH | SOH3# Single SOH3# | R | 2 | | U16 | |
| | | | | | | | | |
| | 11250 | 2BF2H | SOH120# Single SOH120# | R | 2 | | U16 | |
| | 11251 | 2BF3H | SOH updated on: Year/month | R | 2 | | U16 | |
| | 11252 | 2BF4H | Day/Hour | R | 2 | | U16 | |
| | 11253 | 2BF5H | Minutes/second | R | 2 | | U16 | |
| | 11254~ 11260 | Reserved | | | | | | |

4.4 Communication Application

The examples given in this section are in the format of the following table whenever possible (data in hexadecimal)

| Addr | Fun | Data start | | Data #of | | CRC16 | |
|---------|---------------|--------------------|--------|----------------------|--------|------------------------------|-------|
| | | reg Hi | reg Lo | reg Hi | reg Lo | Lo | Hi |
| 01H | 03H | 00H | 00H | 00H | 06H | CRC_L | CRC_H |
| Address | Function Code | Data start address | | Number of data reads | | Cyclic redundancy check code | |

4.4.1 Data reading

Example 1: Read voltage #1 data

| | |
|-------------------|-------------------------|
| Query data frame | 01 03 27 11 00 01 DE BB |
| Return data frame | 01 03 02 34 BC AF 35 |

Description:

01: Slave address

03: Function Code

27 11: Voltage #1 register address

02: Hexadecimal, decimal is 2, which means 2 bytes of data follow

DE BB: Cyclic redundancy check code

The data processing method is shown in the communication parameter address table

Process as follows: 34 BC(hex) = 13500(decimal) Voltage 13500mV

4.4.2 Data writing

Example 2: Set a single overcharge alarm value (3E8H)

| | |
|-------------------|----------------------------------|
| Write data frame | 01 10 3E E8 00 01 02 3A 98 7D 81 |
| Return data frame | 01 10 3E E8 00 01 8C 15 |

Description:

Set the single overcharge alarm value to 15000, i.e. 15000mV

4.5 Solutions to diagnose and troubleshoot common faults

4.5.1 Abnormal data after device power up

Module power-off restart

4.5.2 Abnormal RS-485 communication

1. Check whether the communication baud rate, ID and communication protocol settings of the upper computer are consistent with the device.

2. Please check whether the settings of data bits, stop bits and check bits are consistent with the upper unit.

4.5.3 No data for single modules

1. Check whether the communication wires at both ends of the module are connected tightly.

2. Disconnect the module and check if it is caused by address conflict.

Instruction manual revision record

| Date | Old Version | New Version | Modified content |
|-------------|--------------------|--------------------|---|
| 2023.2.6 | | V1.0 | 1、 First time authoring |
| 2023.5.29 | V1.0 | V1.1 | 1、 update moduel images and add pictures of switch power supply |

